

## MD-23

<b>Overload Flowrate</b>	<b>Q4</b>	<b>3,125</b>	<b><i>m<sup>3</sup>/h</i></b>
<b>Permanent Flowrate</b>	Q3	2,5	<i>m<sup>3</sup>/h</i>
<b>Transitional Flowrate</b>	Q2	0,0200	<i>m<sup>3</sup>/h</i>
<b>Minimum Flowrate</b>	Q1	0,0125	<i>m<sup>3</sup>/h</i>
<b>Ratio</b>	Q3/Q1	200	-
<b>Maximum working pressure</b>	P	16	bar
<b>Pressure Loss Class</b>	-	ΔP63	-
<b>Capacity of calculator</b>		9999/99999/99999,99/99999,999	<i>m<sup>3</sup></i>